
# (ijalastart



## **INSTALL GUIDE**

### 2016 KIA SORENTO PTS SUV AUTOMATIC

#### **DOCUMENT NUMBER**

A971A9

#### REVISION DATE

20200122 160450

#### FIRMWARE

RSA-HK11A

#### HARDWARE

CMHCXA0

#### **ACCESSORIES**

ATTENTION: TO COMPLETE THIS INSTALLATION SOME ACCESSORIES MAY BE REQUIRED. VISIT OUR WEBSITE TO SEE ALL THE REQUIRED ACCESSORIES FOR YOUR VEHICLE.

#### TERMS OF USE

Automotive Data Solutions Inc. ("ADS") products are strictly intended for installation by Certified Technicians who are employed by a registered business specialized in the installation of automotive aftermarket electronics products. Prior to beginning installation of an ADS product in a vehicle, it is the Certified Technician's responsibility to review the most current Product Guide, Install Guide and vehicle-specific notes available in Weblink®. ADS is not responsible for any damages whatsoever, including but not limited to any consequential damages, incidental damages for loss of time, loss of earnings, loss of profit, commercial loss, loss of economic opportunity and the like that may or may not have resulted from the use, misuse, improper installation or operation of its products. ADS reserves itself the right to suspend any Weblink® account without notice and decline to offer technical support to non-Certified Technicians, noncompliant Certified Technicians or end users.






#### **IMPORTANT**


#### A SECURITY PLATE MAY NEED TO BE REMOVED TO ACCESS SMART KEY MODULE CONNECTORS.


USE A BOLT EXTRACTOR AND A RATCHET TO REMOVE THE PLATE'S TAMPER PROOF SCREWS.


USE INCLUDED BOLTS TO REINSTALL SECURITY PLATE IF NECESSARY.














Doc No.: A971A9 - 20200122\_160450















Doc No.: A971A9 - 20200122 160450




T005\_W

PAGE 7 OF 11

Doc No.: A971A9 - 20200122 160450











WARNING: All vehicle doors must be closed and locked prior to remote start sequence. When programming, only one key fob will be used. The other one must be located at least 10 feet away from the vehicle.





Set ignition to ON position.





Wait, LED 1 will turn solid GREEN for 2 seconds.

UJ



Set ignition to OFF position.

04



START vehicle for 15 seconds.

llh.



Press and hold the brake pedal.

06



Press and release the module's programming button

07



Release the brake pedal.

08



Wait, LED 2 will flash GREEN.

09



Module Programming Procedure completed.







All vehicle doors must be closed and locked prior to remote start sequence.





Time restriction. Complete steps 2 to 5 within 45 seconds.

02



Press unlock on OEM or aftermarket remote or request switch.

03



Open driver door and enter vehicle.

04



Close driver door.

llh.



Press and release BRAKE pedal.

06



Take over procedure completed.

>>



Failure to follow procedure will result in vehicle engine shutdown.



Doc No.: A971A9 - 20200122\_160450

	CHECKLIST - WITH AF	TERMAR	KET KEYFOB
1	WARNING: Vehicle engine will start many times. Test in a well ventilated area.	9	Press the START/STOP button once [1x] on the aftermarket keyfob to shut down vehicle.
2	Close all vehicle doors, hood and trunk.		Question 7: Does the vehicle shut down?
3	Press the LOCK button once [1x] on the aftermarket keyfob.		YES: Go to next step.
	Question 1: Do the doors lock?		NO: Repeat step. If problem persists, press the brake pedal once [1x] to shut down the vehicle
	YES: Go to next step.		and call technical support.
	NO: Verify the remote programming, the RF connections and the wired door lock/unlock	10	RAP and auto light shutdown test
	connections as illustrated in the wiring diagram, if applicable. Repeat the test and call technical support, if the problem persists.		<b>Question 8:</b> Did the radio, interior controls and headlights turn off within 60 seconds after remote start shutdown?
4	Press the UNLOCK button once [1x] on the aftermarket keyfob.		YES: Go to next step.
	Question 2: Do the doors unlock?		NO: Verify the RAP SHUTDOWN connections as illustrated in the wiring diagram. Repeat the test and call technical support if the problem persists.
	YES: Go to next step.		
	NO: Verify the remote programming, the RF connections and the wired door lock/unlock	11	Open hood.
	connections as illustrated in the wiring diagram, if applicable. Repeat the test and call technical support, if the problem persists.	12	If not already installed, affix the mandatory orange warning sticker under the hood and proceed to next step.
5	Press the TRUNK release button once [1x] on the aftermarket keyfob if supported.	13	Press the START/STOP button once [1x] on the aftermarket keyfob to remote start vehicle.
	Question 3: Does the trunk or hatch open/unlock?		Question 9: Does the vehicle remote start?
	YES: Close trunk or hatch and go to next step.  NO: Verify the remote programming, the RF connections and the wired trunk/hatch		YES: The vehicle is not equipped with a factory hood pin. Install a mandatory aftermarket hoo switch, then repeat the test.
	connections as illustrated in the wiring diagram, if applicable. Repeat the test and call technical support, if the problem persists.		NO: Go to next step.
		14	Close hood.
6	Press the AUX 1 button once [1x] on the aftermarket keyfob if supported.	15	Enter vehicle and close the doors.
	Question 4: Does the driver side sliding door open?	16	Press the START/STOP button once [1x] on the aftermarket keyfob to remote start vehicle.
	YES: Press the AUX 1 button once [1x] to close the driver sliding door and go to next step.	17	Wait for the vehicle to start.
	NO: Verify the remote programming and the RF connections. Repeat the test and call technical support, if the problem persists.	18	Press brake pedal.
			Question 10: Does the vehicle shut down?
7	Press the AUX 2 button once [1x] on the aftermarket keyfob if supported.		YES: Go to next step.
	Question 5: Does the passenger side sliding door open?		NO: The module does NOT detect the brake pedal signal. Press the START/STOP button once [1x] on the aftermarket keyfob to shut down vehicle, check connection as illustrated in the
	YES: Press the AUX 2 button once [1x] to close the passenger sliding door and go to next step.		
	NO: Verify the remote programming and the RF connections. Repeat the test and call technical support, if the problem persists.	19	wiring diagram, if applicable, and call technical support.  Exit vehicle.
8	Press the START/STOP button once [1x] on the aftermarket keyfob to remote start vehicle.	20	Installation checklist completed.
	Question 6: Does the vehicle remote start?		
	YES: Go to next step.		
	NO: Verify the remote programming, the RF connections and check the remote start error		

codes. Repeat the test and call technical support, if the problem persists.



Doc No.: A971A9 - 20200122\_160450

CHECKLIST - WITH 0EM KEYFOB			
1	WARNING: Vehicle engine will start many times. Test in a well ventilated area.		
2	Close all vehicle doors, hood and trunk.		
3	Press LOCK button three times [3x] rapidly on the OEM keyfob to remote start vehicle.		
	Question 1: Does the vehicle remote start?		
	YES: Go to next step.		
	NO: The module doesn't detect OEM remote lock button from the vehicle communication network. Check all connections, repeat the test and call technical support, if the problem persists.		
4	Press LOCK button three times [3x] rapidly on the OEM keyfob to shut down vehicle.		
	Question 2: Does the vehicle shut down?		
	YES: Go to next step.		
	NO: Repeat step. If the problem persists, press on the brake pedal once [1x] to shut down the vehicle and call technical support.		
5	RAP Shutdown test		
	Question 3: Did the radio, interior controls, and headlights turn off within 60 seconds after remote start shutdown?		
	YES: Go to next step.		
	NO: Verify the RAP SHUTDOWN connections as illustrated in the wiring diagram. Repeat the test and call technical support, if the problem persists.		
6	Open hood.		
7	If not already installed, affix the mandatory orange warning sticker under the hood and proceed to next step.		
8	Press LOCK button three times [3x] rapidly on the OEM keyfob to remote start vehicle.		
	Question 4: Does the vehicle remote start?		
	YES: The vehicle is not equipped with a factory hood pin. Install a mandatory aftermarket hood switch, then repeat the test.		
	NO: Go to next step.		
9	Close hood.		
10	Enter vehicle and close the doors.		
11	Press LOCK button three times [3x] rapidly on the OEM keyfob to remote start vehicle.		
12	Wait for the vehicle to start.		
13	Press brake pedal.		
	Question 5: Does the vehicle shut down?		
	YES: Go to next step.		
	NO: The module does NOT detect the brake pedal signal. Press LOCK button three times [3x] rapidly on the OEM keyfob to shut down, check the brake connection as illustrated in the wiring diagram, if applicable, and call technical support.		
14	Exit vehicle.		
15	Installation checklist completed.		