



HOW TO USE THIS INSTALL GUIDE

- 1** Open the Bookmarks menu and find your vehicle OR scroll down until you find the install guide for your vehicle.
- 2** Print only the pages for your vehicle using the advanced options in the Print menu.
- 3** Install your Maestro AR according to the guide for your vehicle.

WARNING

Pressing the printer icon or “quick printing” this document will print all of the guides in this compilation.



INSTALL GUIDE SUBARU FORESTER 2016-2018

ENABLE A SEAMLESS AFTERMARKET AMPLIFIER INSTALLATION,
WITHOUT CHANGING YOUR RADIO.



KENWOOD

PRODUCTS REQUIRED

iDatalink Maestro AR Amplifier Replacement Interface
iDatalink Maestro aTO3 Installation Harness

OPTIONAL ACCESSORIES

PROGRAMMED FIRMWARE

ADS-AR-TOY03

NOTICE: Automotive Data Solutions Inc. (ADS) recommends having this installation performed by a certified technician. Logos and trademarks used here in are the properties of their respective owners.

WELCOME

Congratulations on the purchase of your iDatalink Maestro / Rockford Fosgate DSR1 Amplifier replacement solution. You are now a few simple steps away from enjoying your new car amplifier.

Before starting your installation, please ensure that your module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Vehicle Wire Reference Chart	5

NEED HELP?

 **1 866 427-2999**

 **support@idatalink.com**

 **maestro.idatalink.com/support**
www.12voltdata.com/forum

INSTALLATION INSTRUCTIONS

STEP 1

- Remove the factory amplifier (refer to wire chart for amplifier location).
- Connect the factory amplifier harnesses to the aT03 T-harness.

STEP 2

- Connect the wires from the aT03 T-harness to the aftermarket amplifier.

Note 1:

If you are running your own speaker wires from the amplifier to the speakers, this step is not necessary.

Note 2:

The amplifier output colors and labels on the aT03 T-harness do not correspond to the vehicle. For vehicle specific wiring designation, see the wiring chart.

- Plug the connector from the aT03 T-Harness into the aftermarket amplifier.
- Plug the Data cable to the data port of the aftermarket amplifier.

STEP 3


- Connect all the harnesses to the Maestro AR module.

Note 3:


The aftermarket amplifier will not turn OFF with the key, it will shut down when the vehicle goes to sleep.

- For technical assistance call 1-866-427-2999 or e-mail "support@idatalink.com". Visit us at "maestro.idatalink.com/support" and "www.12voltdata.com/forum/"

WIRING DIAGRAM



CONNECTIONS NOT REQUIRED



VEHICLE WIRE REFERENCE CHART

T-Harness Wires		Vehicle Wires
Wire Tag	Wire Color	Speaker Wire Description
INPUT 1	White	Right Rear Speaker (+)
	White/Black	Right Rear Speaker (-)
INPUT 2	Gray	Left Rear Speaker (+)
	Gray/Black	Left Rear Speaker (-)
INPUT 3	Orange	Right Subwoofer (+)
	Orange/Black	Right Subwoofer (-)
INPUT 4	Orange	Left Subwoofer (+)
	Orange/Red	Left Subwoofer (-)
INPUT 5	Green	Right Front Speaker (+)
	Green/Black	Right Front Speaker (-)
INPUT 6	Purple	Left Front Speaker (+)
	Purple/Black	Left Front Speaker (-)
INPUT 7	Gray	Left Front Tweeter (+)
	Gray/Red	Left Front Tweeter (-)
INPUT 8	White	Right Front Tweeter (+)
	White/Red	Right Front Tweeter (-)

Note: The amplifier output colors and labels on the aT03 T-harness do not correspond to the vehicle. For vehicle specific wiring designation, follow this wiring chart.

Amplifier location: Under driver seat



INSTALL GUIDE SUBARU WRX 2016-2018

ENABLE A SEAMLESS AFTERMARKET AMPLIFIER INSTALLATION,
WITHOUT CHANGING YOUR RADIO.



KENWOOD

PRODUCTS REQUIRED

iDatalink Maestro AR Amplifier Replacement Interface
iDatalink Maestro aTO3 Installation Harness

OPTIONAL ACCESSORIES

PROGRAMMED FIRMWARE

ADS-AR-TOY03

NOTICE: Automotive Data Solutions Inc. (ADS) recommends having this installation performed by a certified technician. Logos and trademarks used here in are the properties of their respective owners.

WELCOME

Congratulations on the purchase of your iDatalink Maestro / Rockford Fosgate DSR1 Amplifier replacement solution. You are now a few simple steps away from enjoying your new car amplifier.

Before starting your installation, please ensure that your module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

NEED HELP?

 **1 866 427-2999**

 **support@idatalink.com**

 **maestro.idatalink.com/support
www.12voltdata.com/forum**

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Vehicle Wire Reference Chart	5

INSTALLATION INSTRUCTIONS

STEP 1

- Remove the factory amplifier (refer to wire chart for amplifier location).
- Connect the factory amplifier harnesses to the aT03 T-harness.

STEP 2

- Connect the wires from the aT03 T-harness to the aftermarket amplifier.

Note 1:

If you are running your own speaker wires from the amplifier to the speakers, this step is not necessary.

Note 2:

The amplifier output colors and labels on the aT03 T-harness do not correspond to the vehicle. For vehicle specific wiring designation, see the wiring chart.

- Plug the connector from the aT03 T-Harness into the aftermarket amplifier.
- Plug the Data cable to the data port of the aftermarket amplifier.

STEP 3


- Connect all the harnesses to the Maestro AR module.

Note 3:


The aftermarket amplifier will not turn OFF with the key, it will shut down when the vehicle goes to sleep.

- For technical assistance call 1-866-427-2999 or e-mail "support@idatalink.com". Visit us at "maestro.idatalink.com/support" and "www.12voltdata.com/forum/"

WIRING DIAGRAM



CONNECTIONS NOT REQUIRED



VEHICLE WIRE REFERENCE CHART

T-Harness Wires		Vehicle Wires
Wire Tag	Wire Color	Speaker Wire Description
INPUT 1	White	Right Front Tweeter (+)
	White/Black	Right Front Tweeter (-)
INPUT 2	Gray	Left Front Tweeter (+)
	Gray/Black	Left Front Tweeter (-)
INPUT 3	Orange	Subwoofer 2 (+)
	Orange/Black	Subwoofer 2 (-)
INPUT 4	Orange	Subwoofer 1 (+)
	Orange/Red	Subwoofer 1 (-)
INPUT 5	Green	Right Front Speaker (+)
	Green/Black	Right Front Speaker (-)
INPUT 6	Purple	Left Front Speaker (+)
	Purple/Black	Left Front Speaker (-)
INPUT 7	Gray	Left Rear Speaker (+)
	Gray/Red	Left Rear Speaker (-)
INPUT 8	White	Right Rear Speaker (+)
	White/Red	Right Rear Speaker (-)

Note: The amplifier output colors and labels on the aT03 T-harness do not correspond to the vehicle. For vehicle specific wiring designation, follow this wiring chart.

Amplifier location: Under rear deck



INSTALL GUIDE TOYOTA AVALON 2005-2010

ENABLE A SEAMLESS AFTERMARKET AMPLIFIER INSTALLATION,
WITHOUT CHANGING YOUR RADIO.



KENWOOD

PRODUCTS REQUIRED

iDatalink Maestro AR Amplifier Replacement Interface
iDatalink Maestro aTO3 Installation Harness

OPTIONAL ACCESSORIES

PROGRAMMED FIRMWARE

ADS-AR-TOY03

NOTICE: Automotive Data Solutions Inc. (ADS) recommends having this installation performed by a certified technician. Logos and trademarks used here in are the properties of their respective owners.

WELCOME

Congratulations on the purchase of your iDatalink Maestro / Rockford Fosgate DSR1 Amplifier replacement solution. You are now a few simple steps away from enjoying your new car amplifier.

Before starting your installation, please ensure that your module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

NEED HELP?

 **1 866 427-2999**

 **support@idatalink.com**

 **maestro.idatalink.com/support
www.12voltdata.com/forum**

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Vehicle Wire Reference Chart	5

INSTALLATION INSTRUCTIONS

STEP 1

- Remove the factory amplifier (refer to wire chart for amplifier location).
- Connect the factory amplifier harnesses to the aT03 T-harness.

STEP 2

- Connect the wires from the aT03 T-harness to the aftermarket amplifier.

Note 1:

If you are running your own speaker wires from the amplifier to the speakers, this step is not necessary.

Note 2:

The amplifier output colors and labels on the aT03 T-harness do not correspond to the vehicle. For vehicle specific wiring designation, see the wiring chart.

- Plug the connector from the aT03 T-Harness into the aftermarket amplifier.
- Plug the Data cable to the data port of the aftermarket amplifier.

STEP 3


- Connect all the harnesses to the Maestro AR module.

Note 3:


The aftermarket amplifier will not turn OFF with the key, it will shut down when the vehicle goes to sleep.

- For technical assistance call 1-866-427-2999 or e-mail "support@idatalink.com". Visit us at "maestro.idatalink.com/support" and "www.12voltdata.com/forum/"

WIRING DIAGRAM



CONNECTIONS NOT REQUIRED



VEHICLE WIRE REFERENCE CHART

T-Harness Wires		Vehicle Wires
Wire Tag	Wire Color	Speaker Wire Description
INPUT 1	White	Left Front Speaker (+)
	White/Black	Left Front Speaker (-)
INPUT 2	Gray	Right Front Speaker (+)
	Gray/Black	Right Front Speaker (-)
INPUT 3	Orange	Left Rear Shelf Speaker (+)
	Orange/Black	Left Rear Shelf Speaker (-)
INPUT 4	Orange	Subwoofer 1 (+)
	Orange/Red	Subwoofer 1 (-)
INPUT 5	Green	Left Rear Speaker (+)
	Green/Black	Left Rear Speaker (-)
INPUT 6	Purple	Right Rear Speaker (+)
	Purple/Black	Right Rear Speaker (-)
INPUT 7	Gray	Right Rear Shelf Speaker (+)
	Gray/Red	Right Rear Shelf Speaker (-)
INPUT 8	White	Center (+)
	White/Red	Center (-)

Note: The amplifier output colors and labels on the aT03 T-harness do not correspond to the vehicle. For vehicle specific wiring designation, follow this wiring chart.

Amplifier location: Under passenger seat



INSTALL GUIDE TOYOTA CAMRY 2007-2011

ENABLE A SEAMLESS AFTERMARKET AMPLIFIER INSTALLATION,
WITHOUT CHANGING YOUR RADIO.



KENWOOD

PRODUCTS REQUIRED

iDatalink Maestro AR Amplifier Replacement Interface
iDatalink Maestro aTO3 Installation Harness

OPTIONAL ACCESSORIES

PROGRAMMED FIRMWARE

ADS-AR-TOY03

NOTICE: Automotive Data Solutions Inc. (ADS) recommends having this installation performed by a certified technician. Logos and trademarks used here in are the properties of their respective owners.

WELCOME

Congratulations on the purchase of your iDatalink Maestro / Rockford Fosgate DSR1 Amplifier replacement solution. You are now a few simple steps away from enjoying your new car amplifier.

Before starting your installation, please ensure that your module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Vehicle Wire Reference Chart	5

NEED HELP?

 **1 866 427-2999**

 **support@idatalink.com**

 **maestro.idatalink.com/support
www.12voltdata.com/forum**

INSTALLATION INSTRUCTIONS

STEP 1

- Remove the factory amplifier (refer to wire chart for amplifier location).
- Connect the factory amplifier harnesses to the aT03 T-harness.

STEP 2

- Connect the wires from the aT03 T-harness to the aftermarket amplifier.

Note 1:

If you are running your own speaker wires from the amplifier to the speakers, this step is not necessary.

Note 2:

The amplifier output colors and labels on the aT03 T-harness do not correspond to the vehicle. For vehicle specific wiring designation, see the wiring chart.

- Plug the connector from the aT03 T-Harness into the aftermarket amplifier.
- Plug the Data cable to the data port of the aftermarket amplifier.

STEP 3


- Connect all the harnesses to the Maestro AR module.

Note 3:


The aftermarket amplifier will not turn OFF with the key, it will shut down when the vehicle goes to sleep.

- For technical assistance call 1-866-427-2999 or e-mail "support@idatalink.com". Visit us at "maestro.idatalink.com/support" and "www.12voltdata.com/forum/"

WIRING DIAGRAM



CONNECTIONS NOT REQUIRED



VEHICLE WIRE REFERENCE CHART

T-Harness Wires		Vehicle Wires
Wire Tag	Wire Color	Speaker Wire Description
INPUT 1	White	Left Front Speaker (+)
	White/Black	Left Front Speaker (-)
INPUT 2	Gray	Right Front Speaker (+)
	Gray/Black	Right Front Speaker (-)
INPUT 3	Orange	Left Rear Shelf Speaker (+)
	Orange/Black	Left Rear Shelf Speaker (-)
INPUT 4	Orange	Right Rear Shelf Speaker (+)
	Orange/Red	Right Rear Shelf Speaker (-)
INPUT 5	Green	Left Rear Speaker (+)
	Green/Black	Left Rear Speaker (-)
INPUT 6	Purple	Right Rear Speaker (+)
	Purple/Black	Right Rear Speaker (-)
INPUT 7	Gray	Right Front Tweeter (+)
	Gray/Red	Right Front Tweeter (-)
INPUT 8	White	Left Front Tweeter (+)
	White/Red	Left Front Tweeter (-)

Note: The amplifier output colors and labels on the aT03 T-harness do not correspond to the vehicle. For vehicle specific wiring designation, follow this wiring chart.

Amplifier location: Under passenger seat



INSTALL GUIDE TOYOTA COROLLA 2009-2010

ENABLE A SEAMLESS AFTERMARKET AMPLIFIER INSTALLATION,
WITHOUT CHANGING YOUR RADIO.



KENWOOD

PRODUCTS REQUIRED

iDatalink Maestro AR Amplifier Replacement Interface
iDatalink Maestro aTO3 Installation Harness

OPTIONAL ACCESSORIES

PROGRAMMED FIRMWARE

ADS-AR-TOY03

NOTICE: Automotive Data Solutions Inc. (ADS) recommends having this installation performed by a certified technician. Logos and trademarks used here in are the properties of their respective owners.

WELCOME

Congratulations on the purchase of your iDatalink Maestro / Rockford Fosgate DSR1 Amplifier replacement solution. You are now a few simple steps away from enjoying your new car amplifier.

Before starting your installation, please ensure that your module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

NEED HELP?

 **1 866 427-2999**

 **support@idatalink.com**

 **maestro.idatalink.com/support
www.12voltdata.com/forum**

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Vehicle Wire Reference Chart	5

INSTALLATION INSTRUCTIONS

STEP 1

- Remove the factory amplifier (refer to wire chart for amplifier location).
- Connect the factory amplifier harnesses to the aT03 T-harness.

STEP 2

- Connect the wires from the aT03 T-harness to the aftermarket amplifier.

Note 1:

If you are running your own speaker wires from the amplifier to the speakers, this step is not necessary.

Note 2:

The amplifier output colors and labels on the aT03 T-harness do not correspond to the vehicle. For vehicle specific wiring designation, see the wiring chart.

- Plug the connector from the aT03 T-Harness into the aftermarket amplifier.
- Plug the Data cable to the data port of the aftermarket amplifier.

STEP 3


- Connect all the harnesses to the Maestro AR module.

Note 3:


The aftermarket amplifier will not turn OFF with the key, it will shut down when the vehicle goes to sleep.

- For technical assistance call 1-866-427-2999 or e-mail "support@idatalink.com". Visit us at "maestro.idatalink.com/support" and "www.12voltdata.com/forum/"

WIRING DIAGRAM



CONNECTIONS NOT REQUIRED



VEHICLE WIRE REFERENCE CHART

T-Harness Wires		Vehicle Wires
Wire Tag	Wire Color	Speaker Wire Description
INPUT 1	White	Left Front Speaker (+)
	White/Black	Left Front Speaker (-)
INPUT 2	Gray	Right Front Speaker (+)
	Gray/Black	Right Front Speaker (-)
INPUT 3	Orange	Left Rear Shelf Speaker (+)
	Orange/Black	Left Rear Shelf Speaker (-)
INPUT 4	Orange	Right Rear Shelf Speaker (+)
	Orange/Red	Right Rear Shelf Speaker (-)
INPUT 5	Green	Left Rear Speaker (+)
	Green/Black	Left Rear Speaker (-)
INPUT 6	Purple	Right Rear Speaker (+)
	Purple/Black	Right Rear Speaker (-)
INPUT 7	Gray	Right Front Tweeter (+)
	Gray/Red	Right Front Tweeter (-)
INPUT 8	White	Left Front Tweeter (+)
	White/Red	Left Front Tweeter (-)

Note: The amplifier output colors and labels on the aT03 T-harness do not correspond to the vehicle. For vehicle specific wiring designation, follow this wiring chart.

Amplifier location: Under passenger seat



INSTALL GUIDE TOYOTA HIGHLANDER 2008-2013

ENABLE A SEAMLESS AFTERMARKET AMPLIFIER INSTALLATION,
WITHOUT CHANGING YOUR RADIO.



KENWOOD

PRODUCTS REQUIRED

iDatalink Maestro AR Amplifier Replacement Interface
iDatalink Maestro aTO3 Installation Harness

OPTIONAL ACCESSORIES

PROGRAMMED FIRMWARE

ADS-AR-TOY03

NOTICE: Automotive Data Solutions Inc. (ADS) recommends having this installation performed by a certified technician. Logos and trademarks used here in are the properties of their respective owners.

WELCOME

Congratulations on the purchase of your iDatalink Maestro / Rockford Fosgate DSR1 Amplifier replacement solution. You are now a few simple steps away from enjoying your new car amplifier.

Before starting your installation, please ensure that your module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

NEED HELP?

 **1 866 427-2999**

 **support@idatalink.com**

 **maestro.idatalink.com/support
www.12voltdata.com/forum**

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Vehicle Wire Reference Chart	5

INSTALLATION INSTRUCTIONS

STEP 1

- Remove the factory amplifier (refer to wire chart for amplifier location).
- Connect the factory amplifier harnesses to the aT03 T-harness.

STEP 2

- Connect the wires from the aT03 T-harness to the aftermarket amplifier.

Note 1:

If you are running your own speaker wires from the amplifier to the speakers, this step is not necessary.

Note 2:

The amplifier output colors and labels on the aT03 T-harness do not correspond to the vehicle. For vehicle specific wiring designation, see the wiring chart.

- Plug the connector from the aT03 T-Harness into the aftermarket amplifier.
- Plug the Data cable to the data port of the aftermarket amplifier.

STEP 3


- Connect all the harnesses to the Maestro AR module.

Note 3:


The aftermarket amplifier will not turn OFF with the key, it will shut down when the vehicle goes to sleep.

- For technical assistance call 1-866-427-2999 or e-mail "support@idatalink.com". Visit us at "maestro.idatalink.com/support" and "www.12voltdata.com/forum/"

WIRING DIAGRAM



CONNECTIONS NOT REQUIRED



VEHICLE WIRE REFERENCE CHART

T-Harness Wires		Vehicle Wires
Wire Tag	Wire Color	Speaker Wire Description
INPUT 1	White	Left Front Speaker (+)
	White/Black	Left Front Speaker (-)
INPUT 2	Gray	Right Front Speaker (+)
	Gray/Black	Right Front Speaker (-)
INPUT 3	Orange	Right Subwoofer (+)
	Orange/Black	Right Subwoofer (-)
INPUT 4	Orange	Left Subwoofer (+)
	Orange/Red	Left Subwoofer (-)
INPUT 5	Green	Left Rear Speaker (+)
	Green/Black	Left Rear Speaker (-)
INPUT 6	Purple	Right Rear Speaker (+)
	Purple/Black	Right Rear Speaker (-)
INPUT 7	Gray	Right Front Tweeter (+)
	Gray/Red	Right Front Tweeter (-)
INPUT 8	White	Left Front Tweeter (+)
	White/Red	Left Front Tweeter (-)

Note: The amplifier output colors and labels on the aT03 T-harness do not correspond to the vehicle. For vehicle specific wiring designation, follow this wiring chart.

Amplifier location: Under passenger seat



INSTALL GUIDE TOYOTA PRIUS 2006-2011

ENABLE A SEAMLESS AFTERMARKET AMPLIFIER INSTALLATION,
WITHOUT CHANGING YOUR RADIO.



KENWOOD

PRODUCTS REQUIRED

iDatalink Maestro AR Amplifier Replacement Interface
iDatalink Maestro aTO3 Installation Harness

OPTIONAL ACCESSORIES

PROGRAMMED FIRMWARE

ADS-AR-TOY03

NOTICE: Automotive Data Solutions Inc. (ADS) recommends having this installation performed by a certified technician. Logos and trademarks used here in are the properties of their respective owners.

WELCOME

Congratulations on the purchase of your iDatalink Maestro / Rockford Fosgate DSR1 Amplifier replacement solution. You are now a few simple steps away from enjoying your new car amplifier.

Before starting your installation, please ensure that your module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Vehicle Wire Reference Chart	5

NEED HELP?

 **1 866 427-2999**

 **support@idatalink.com**

 **maestro.idatalink.com/support
www.12voltdata.com/forum**

INSTALLATION INSTRUCTIONS

STEP 1

- Remove the factory amplifier (refer to wire chart for amplifier location).
- Connect the factory amplifier harnesses to the aT03 T-harness.

STEP 2

- Connect the wires from the aT03 T-harness to the aftermarket amplifier.

Note 1:

If you are running your own speaker wires from the amplifier to the speakers, this step is not necessary.

Note 2:

The amplifier output colors and labels on the aT03 T-harness do not correspond to the vehicle. For vehicle specific wiring designation, see the wiring chart.

- Plug the connector from the aT03 T-Harness into the aftermarket amplifier.
- Plug the Data cable to the data port of the aftermarket amplifier.

STEP 3


- Connect all the harnesses to the Maestro AR module.

Note 3:


The aftermarket amplifier will not turn OFF with the key, it will shut down when the vehicle goes to sleep.

- For technical assistance call 1-866-427-2999 or e-mail "support@idatalink.com". Visit us at "maestro.idatalink.com/support" and "www.12voltdata.com/forum/"

WIRING DIAGRAM



CONNECTIONS NOT REQUIRED



VEHICLE WIRE REFERENCE CHART

T-Harness Wires		Vehicle Wires
Wire Tag	Wire Color	Speaker Wire Description
INPUT 1	White	Left Front Speaker (+)
	White/Black	Left Front Speaker (-)
INPUT 2	Gray	Right Front Speaker (+)
	Gray/Black	Right Front Speaker (-)
INPUT 3	Orange	Center (+)
	Orange/Black	Center (-)
INPUT 4	Orange	n/a
	Orange/Red	n/a
INPUT 5	Green	Left Rear Speaker (+)
	Green/Black	Left Rear Speaker (-)
INPUT 6	Purple	Right Rear Speaker (+)
	Purple/Black	Right Rear Speaker (-)
INPUT 7	Gray	Right Front Tweeter (+)
	Gray/Red	Right Front Tweeter (-)
INPUT 8	White	Left Front Tweeter (+)
	White/Red	Left Front Tweeter (-)

Note: The amplifier output colors and labels on the aT03 T-harness do not correspond to the vehicle. For vehicle specific wiring designation, follow this wiring chart.

Amplifier location: Under passenger seat



INSTALL GUIDE TOYOTA RAV 4 2006-2012

ENABLE A SEAMLESS AFTERMARKET AMPLIFIER INSTALLATION,
WITHOUT CHANGING YOUR RADIO.



KENWOOD

PRODUCTS REQUIRED

iDatalink Maestro AR Amplifier Replacement Interface
iDatalink Maestro aTO3 Installation Harness

OPTIONAL ACCESSORIES

PROGRAMMED FIRMWARE

ADS-AR-TOY03

NOTICE: Automotive Data Solutions Inc. (ADS) recommends having this installation performed by a certified technician. Logos and trademarks used here in are the properties of their respective owners.

WELCOME

Congratulations on the purchase of your iDatalink Maestro / Rockford Fosgate DSR1 Amplifier replacement solution. You are now a few simple steps away from enjoying your new car amplifier.

Before starting your installation, please ensure that your module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Vehicle Wire Reference Chart	5

NEED HELP?

 **1 866 427-2999**

 **support@idatalink.com**

 **maestro.idatalink.com/support**
www.12voltdata.com/forum

INSTALLATION INSTRUCTIONS

STEP 1

- Remove the factory amplifier (refer to wire chart for amplifier location).
- Connect the factory amplifier harnesses to the aT03 T-harness.

STEP 2

- Connect the wires from the aT03 T-harness to the aftermarket amplifier.

Note 1:

If you are running your own speaker wires from the amplifier to the speakers, this step is not necessary.

Note 2:

The amplifier output colors and labels on the aT03 T-harness do not correspond to the vehicle. For vehicle specific wiring designation, see the wiring chart.

- Plug the connector from the aT03 T-Harness into the aftermarket amplifier.
- Plug the Data cable to the data port of the aftermarket amplifier.

STEP 3


- Connect all the harnesses to the Maestro AR module.

Note 3:


The aftermarket amplifier will not turn OFF with the key, it will shut down when the vehicle goes to sleep.

- For technical assistance call 1-866-427-2999 or e-mail "support@idatalink.com". Visit us at "maestro.idatalink.com/support" and "www.12voltdata.com/forum/"

WIRING DIAGRAM



CONNECTIONS NOT REQUIRED



VEHICLE WIRE REFERENCE CHART

T-Harness Wires		Vehicle Wires
Wire Tag	Wire Color	Speaker Wire Description
INPUT 1	White	Left Front Speaker (+)
	White/Black	Left Front Speaker (-)
INPUT 2	Gray	Right Front Speaker (+)
	Gray/Black	Right Front Speaker (-)
INPUT 3	Orange	Right Subwoofer (+)
	Orange/Black	Right Subwoofer (-)
INPUT 4	Orange	Left Subwoofer (+)
	Orange/Red	Left Subwoofer (-)
INPUT 5	Green	Left Rear Speaker (+)
	Green/Black	Left Rear Speaker (-)
INPUT 6	Purple	Right Rear Speaker (+)
	Purple/Black	Right Rear Speaker (-)
INPUT 7	Gray	Right Front Tweeter (+)
	Gray/Red	Right Front Tweeter (-)
INPUT 8	White	Left Front Tweeter (+)
	White/Red	Left Front Tweeter (-)

Note: The amplifier output colors and labels on the aT03 T-harness do not correspond to the vehicle. For vehicle specific wiring designation, follow this wiring chart.

Amplifier location: Right D pillar



INSTALL GUIDE TOYOTA TACOMA 2009-2018

ENABLE A SEAMLESS AFTERMARKET AMPLIFIER INSTALLATION,
WITHOUT CHANGING YOUR RADIO.



KENWOOD

PRODUCTS REQUIRED

iDatalink Maestro AR Amplifier Replacement Interface
iDatalink Maestro aTO3 Installation Harness

OPTIONAL ACCESSORIES

PROGRAMMED FIRMWARE

ADS-AR-TOY03

NOTICE: Automotive Data Solutions Inc. (ADS) recommends having this installation performed by a certified technician. Logos and trademarks used here in are the properties of their respective owners.

WELCOME

Congratulations on the purchase of your iDatalink Maestro / Rockford Fosgate DSR1 Amplifier replacement solution. You are now a few simple steps away from enjoying your new car amplifier.

Before starting your installation, please ensure that your module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Vehicle Wire Reference Chart	5

NEED HELP?

 **1 866 427-2999**

 **support@idatalink.com**

 **maestro.idatalink.com/support**
www.12voltdata.com/forum

INSTALLATION INSTRUCTIONS

STEP 1

- Remove the factory amplifier (refer to wire chart for amplifier location).
- Connect the factory amplifier harnesses to the aT03 T-harness.

STEP 2

- Connect the wires from the aT03 T-harness to the aftermarket amplifier.

Note 1:

If you are running your own speaker wires from the amplifier to the speakers, this step is not necessary.

Note 2:

The amplifier output colors and labels on the aT03 T-harness do not correspond to the vehicle. For vehicle specific wiring designation, see the wiring chart.

- Plug the connector from the aT03 T-Harness into the aftermarket amplifier.
- Plug the Data cable to the data port of the aftermarket amplifier.

STEP 3


- Connect all the harnesses to the Maestro AR module.

Note 3:


The aftermarket amplifier will not turn OFF with the key, it will shut down when the vehicle goes to sleep.

- For technical assistance call 1-866-427-2999 or e-mail "support@idatalink.com". Visit us at "maestro.idatalink.com/support" and "www.12voltdata.com/forum/"

WIRING DIAGRAM



CONNECTIONS NOT REQUIRED



VEHICLE WIRE REFERENCE CHART

T-Harness Wires		Vehicle Wires
Wire Tag	Wire Color	Speaker Wire Description
INPUT 1	White	Left Front Speaker (+)
	White/Black	Left Front Speaker (-)
INPUT 2	Gray	Right Front Speaker (+)
	Gray/Black	Right Front Speaker (-)
INPUT 3	Orange	Right Subwoofer (+)
	Orange/Black	Right Subwoofer (-)
INPUT 4	Orange	Left Subwoofer (+)
	Orange/Red	Left Subwoofer (-)
INPUT 5	Green	Left Rear Speaker (+)
	Green/Black	Left Rear Speaker (-)
INPUT 6	Purple	Right Rear Speaker (+)
	Purple/Black	Right Rear Speaker (-)
INPUT 7	Gray	Right Front Tweeter (+)
	Gray/Red	Right Front Tweeter (-)
INPUT 8	White	Left Front Tweeter (+)
	White/Red	Left Front Tweeter (-)

Note: The amplifier output colors and labels on the aT03 T-harness do not correspond to the vehicle. For vehicle specific wiring designation, follow this wiring chart.

Amplifier location: Near C pillar



INSTALL GUIDE TOYOTA TUNDRA 2009-2018

ENABLE A SEAMLESS AFTERMARKET AMPLIFIER INSTALLATION,
WITHOUT CHANGING YOUR RADIO.



KENWOOD

PRODUCTS REQUIRED

iDatalink Maestro AR Amplifier Replacement Interface
iDatalink Maestro aTO3 Installation Harness

OPTIONAL ACCESSORIES

PROGRAMMED FIRMWARE

ADS-AR-TOY03

NOTICE: Automotive Data Solutions Inc. (ADS) recommends having this installation performed by a certified technician. Logos and trademarks used here in are the properties of their respective owners.

WELCOME

Congratulations on the purchase of your iDatalink Maestro / Rockford Fosgate DSR1 Amplifier replacement solution. You are now a few simple steps away from enjoying your new car amplifier.

Before starting your installation, please ensure that your module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.


TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Vehicle Wire Reference Chart	5

NEED HELP?

 **1 866 427-2999**

 **support@idatalink.com**

 **maestro.idatalink.com/support
www.12voltdata.com/forum**

INSTALLATION INSTRUCTIONS

STEP 1

- Remove the factory amplifier (refer to wire chart for amplifier location).
- Connect the factory amplifier harnesses to the aT03 T-harness.

STEP 2

- Connect the wires from the aT03 T-harness to the aftermarket amplifier.

Note 1:

If you are running your own speaker wires from the amplifier to the speakers, this step is not necessary.

Note 2:

The amplifier output colors and labels on the aT03 T-harness do not correspond to the vehicle. For vehicle specific wiring designation, see the wiring chart.

- Plug the connector from the aT03 T-Harness into the aftermarket amplifier.
- Plug the Data cable to the data port of the aftermarket amplifier.

STEP 3


- Connect all the harnesses to the Maestro AR module.

Note 3:


The aftermarket amplifier will not turn OFF with the key, it will shut down when the vehicle goes to sleep.

- For technical assistance call 1-866-427-2999 or e-mail "support@idatalink.com". Visit us at "maestro.idatalink.com/support" and "www.12voltdata.com/forum/"

WIRING DIAGRAM



CONNECTIONS NOT REQUIRED



VEHICLE WIRE REFERENCE CHART

T-Harness Wires		Vehicle Wires
Wire Tag	Wire Color	Speaker Wire Description
INPUT 1	White	Left Front Speaker (+)
	White/Black	Left Front Speaker (-)
INPUT 2	Gray	Right Front Speaker (+)
	Gray/Black	Right Front Speaker (-)
INPUT 3	Orange	Center (+)
	Orange/Black	Center (-)
INPUT 4	Orange	Subwoofer (+)
	Orange/Red	Subwoofer (-)
INPUT 5	Green	Left Rear Speaker (+)
	Green/Black	Left Rear Speaker (-)
INPUT 6	Purple	Right Rear Speaker (+)
	Purple/Black	Right Rear Speaker (-)
INPUT 7	Gray	Right Front Tweeter (+)
	Gray/Red	Right Front Tweeter (-)
INPUT 8	White	Left Front Tweeter (+)
	White/Red	Left Front Tweeter (-)

Note: The amplifier output colors and labels on the aT03 T-harness do not correspond to the vehicle. For vehicle specific wiring designation, follow this wiring chart.

Amplifier location: Under passenger seat