



HOW TO USE THIS INSTALL GUIDE

- 1** Open the Bookmarks menu and find your vehicle OR scroll down until you find the install guide for your vehicle.
- 2** Print only the pages for your vehicle using the advanced options in the Print menu.
- 3** Install your Maestro RR according to the guide for your vehicle.

WARNING

Pressing the printer icon or “quick printing” this document will print all of the guides in this compilation.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDataLink Maestro RR or RR2 Radio Replacement Interface
iDataLink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female RED connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDatalink Maestro RR or RR2 Radio Replacement Interface
iDatalink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female RED connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM











RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
 or 		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDataLink Maestro RR or RR2 Radio Replacement Interface
iDataLink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female RED connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM














RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
 or 		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDatalink Maestro RR or RR2 Radio Replacement Interface
iDatalink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female RED connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDatalink Maestro RR or RR2 Radio Replacement Interface
iDatalink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)

WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female BLACK connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDataLink Maestro RR or RR2 Radio Replacement Interface
iDataLink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector (**2.1**) and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female BLACK connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDatalink Maestro RR or RR2 Radio Replacement Interface
iDatalink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female RED connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDataLink Maestro RR or RR2 Radio Replacement Interface
iDataLink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)

WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female RED connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDataLink Maestro RR or RR2 Radio Replacement Interface
iDataLink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)

WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female RED connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDataLink Maestro RR or RR2 Radio Replacement Interface
iDataLink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female RED connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDataLINK Maestro RR or RR2 Radio Replacement Interface
iDataLINK Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female RED connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDataLink Maestro RR or RR2 Radio Replacement Interface
iDataLink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female BLACK connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE
 Phone: 1-866-427-2999
 Email: maestro.support@idatalink.com
 Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDataLink Maestro RR or RR2 Radio Replacement Interface
iDataLink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female RED connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDataLINK Maestro RR or RR2 Radio Replacement Interface
iDataLINK Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female BLACK connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDatalink Maestro RR or RR2 Radio Replacement Interface
iDatalink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female BLACK connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDatalink Maestro RR or RR2 Radio Replacement Interface
iDatalink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)

WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector (**2.1**) and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female BLACK connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDataLINK Maestro RR or RR2 Radio Replacement Interface
iDataLINK Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES

K40[™]
ELECTRONICS
ESCORT

Click here for:
[Radar Installation Guides](#)

WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector (2.1) and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female BLACK connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDataLINK Maestro RR or RR2 Radio Replacement Interface
iDataLINK Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female BLACK connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM











RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
 or 		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDatalink Maestro RR or RR2 Radio Replacement Interface
iDatalink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES

K40[™]
ELECTRONICS
ESCORT

Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female BLACK connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDataLink Maestro RR or RR2 Radio Replacement Interface
iDataLink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female RED connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltage.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDataLINK Maestro RR or RR2 Radio Replacement Interface
iDataLINK Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female RED connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDataLINK Maestro RR or RR2 Radio Replacement Interface
iDataLINK Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female RED connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDatalink Maestro RR or RR2 Radio Replacement Interface
iDatalink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female BLACK connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDatalink Maestro RR or RR2 Radio Replacement Interface
iDatalink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES

K40[™]
ELECTRONICS
ESCORT

Click here for:
[Radar Installation Guides](#)

WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female BLACK connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM












RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
 or 		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDatalink Maestro RR or RR2 Radio Replacement Interface
iDatalink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)

WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female RED connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDataLINK Maestro RR or RR2 Radio Replacement Interface
iDataLINK Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female BLACK connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDataLINK Maestro RR or RR2 Radio Replacement Interface
iDataLINK Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female BLACK connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.

STEP 7

- To connect reverse camera, connect PURPLE/WHITE Reverse Light (+) wire from aftermarket radio to White/Gray wire in harness in passenger kick panel.


Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 8

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDataLink Maestro RR or RR2 Radio Replacement Interface
iDataLink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female RED connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDataLink Maestro RR or RR2 Radio Replacement Interface
iDataLink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

Note: VES cannot be retained in this vehicle.

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.




Fig. 2.1

- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female BLACK connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.
- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDatalink Maestro RR or RR2 Radio Replacement Interface
iDatalink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES

K40[™]
ELECTRONICS
ESCORT

Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female BLACK connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM



RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, AND MORE!



PRODUCTS REQUIRED

iDatalink Maestro RR or RR2 Radio Replacement Interface
iDatalink Maestro CH1 Installation Harness

PROGRAMMED FIRMWARE

ADS-RR(SR)-CHR01-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)


WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

 maestro.idatalink.com/support
www.12voltdata.com/forum

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	4
Radio Wire Reference Chart	5
Module Diagnostics	6
Troubleshooting Table	7

INSTALLATION INSTRUCTIONS P1/1

STEP 1

- Unbox the aftermarket radio and locate its main harness.
- Connect the wires shown on the next page from aftermarket radio main harness to the CH1 T-harness and match the wire functions.

STEP 2

- Remove the factory radio.
- Access the main 22 pin factory radio connector **(2.1)** and determine if you have a factory amplifier.




Fig. 2.1

If you don't have wires in PIN 19, 20, 21 and 22, you have a factory amplifier:

- Plug the female GREEN connector to the male GREEN connector of your CH1 T-harness.
- Plug the female WHITE connector to the male WHITE connector of your CH1 T-harness.

If you have wires in PIN 19, 20, 21 and 22, you don't have a factory amplifier:

- Plug the female GREEN connector to the male WHITE connector of your CH1 T-harness.
- Plug the female WHITE connector to the male GREEN connector of your CH1 T-harness.

STEP 3

- Plug the female BLACK connector to the male BLACK connector.

STEP 4

- Connect the factory harness to the CH1 T-harness.

STEP 5

- Access the OBDII connector located under the driver side dashboard.

- Connect the RED/BROWN wire of the CH1 T-harness to the wire located at pin 6 of the OBDII connector. (See the vehicle wire chart reference for wire colors)
- Connect the YELLOW/BROWN wire of the CH1 T-harness to the wire located at pin 14 of the OBDII connector. (See the vehicle wire chart reference for wire colors)

STEP 6

- Plug the aftermarket radio harnesses into the aftermarket radio.
- Plug the Data cable to the data port of the aftermarket radio.

Note: On Pioneer radio, ensure that there is nothing plugged into the W/R port.


Note: Refer to radio wire chart for radio's reverse light wire color.

If no camera is installed/desired, do not connect the radio's reverse wire. If installing an aftermarket camera, do NOT connect power for the camera to the Maestro's purple/white wire or module damage will occur.

STEP 7

- Connect all the harnesses to the Maestro RR module then test your installation.

WIRING DIAGRAM











RADIO WIRE REFERENCE CHART

Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
Foot Brake	(+)	Yellow/Black	Yellow/Black	N/A	N/A	N/A
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
 or 		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure OBDII connector is securely attached to the OBD2 connector of the vehicle.</p> <p>If you hardwired connections at the OBDII, check connections at the OBDII connector. Make sure the RED/BROWN wire is on PIN 6 and the YELLOW/BROWN wire is connected to PIN 14 of the OBDII connector. Do not use T-Taps. Soldering or military splicing methods are recommended.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
When making a phone call you cannot hear the callers but they can hear you.	Switch the 4-pin green and white connectors in the t-harness.
The radio doesn't turn on. LED on the Maestro is not flashing.	Ensure the black and red 2-pin connectors are connected as shown in the diagram. Test for power at the large 3 pin connector of the harness. With it plugged in and vehicle turned on, we should have power on the red and yellow wires.
There isn't a connector in the dash for the 10 pin gray plug of the t-harness.	That is fine. Not every vehicle will have it, and it's not essential for proper radio operation.
The light on the Maestro is flashing RED ONCE .	There is no firmware on the module; flash the RR module.
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>
The light on the Maestro is blinking RED TWICE but radio is NOT turning on.	If installing a floating screen type radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error.
No sound.	Ensure blue/white wire from harness is connected to radio's amp turn on output. This is usually blue/white but varies by radio manufacturer. Verify speaker wire connections and 4 pin connectors (green and white).

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999

Email: maestro.support@idatalink.com

Web: maestro.idatalink.com/support-add www.12voltdata.com/forum/

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.